

Technical Bulletin

Date: May 24, 2017

Subject: Changes to DIRECTV Dish Type Settings

DIRECTV® has modified the available Dish Type choices in its latest version of receiver software. These new settings differ slightly from the settings described in the TracVision® manuals and Setup Wizard. Therefore, use the new Dish Type settings listed below when configuring receivers to work with a TracVision system.

Note: Switch Type should auto-populate when you select the Dish Type. Keep RB/INTL set to None.

TracVision HD7 and HD11

Receiver Type	Dish Type	Switch Type
SWM	SL3 LNB (was Slimline-3)	SWM Module 8 CH
Non-SWM	18" Round LNB (was Round)	Multiswitch



TracVision TV-series, RV1, and A9

Receiver Type	Satellite(s) Needed*	Dish Type	Switch Type
SWM	101W and 119W	18x20" Triple-sat LNB (was 3-LNB)	SWM Module 8 CH
SWM	101W only	18" Round LNB (was Round)	SWM Module 8 CH
Non-SWM	101W and 119W	18x20" Triple-sat LNB (was 3-LNB)	Multiswitch
Non-SWM	101W only	18" Round LNB (was Round)	Multiswitch

* The 119W satellite carries just local channels for certain regions of the U.S.
See www.kvh.com/dtv119locals for the latest list.

If you have any questions about this issue, please contact KVH Technical Support at +1 401 847-3327 or via email at support@kvh.com.